

Supplement to Operations Manual B-PCOM Calibration Procedure for TITUS II Controller

A. Direct Acting Cooling or Reverse Acting Heating.

1. Adjusting minimum air flow:

- a. Apply zero PSI signal to port T on the controller.
- b. If the minimum CFM equals zero, the damper should drive to a closed position with compressed air (observe the indicator on the end of the damper shaft). If not, adjust the LO knob on the controller until the damper is closed.
- c. If a non-zero minimum CFM is required, read the differential pressure for the desired CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (B-PCOM figure 5). Adjust the LO knob until the desired differential pressure is read on the manometer gauge. Allow several seconds for the controls to react to the system pressure and stabilize. Note: Air flow must be going across the Inlet probe.

2. Adjusting maximum air flow:

- a. Apply 15-25 PSI signal to port T on the controller.

- b. Refer again to the calibration curve (B-PCOM figure 5) to determine the differential pressure necessary for the required CFM.

- c. Adjust the HI knob on the controller until the manometer gauge reads the required differential pressure from the curve.

NOTE: If actuator fails to respond, see Guide to Service Procedures B-PCOM.

B. Reverse Acting Cooling and Direct Acting Heating.

1. Adjusting minimum air flow:

- a. Apply 15-25 PSI signal to port T on the controller.
- b. If the minimum CFM equals zero, the damper should assume a closed position (observe the indicator on the end of the damper shaft). If not, adjust LO knob on the controller until the damper closes.


- c. If a non-zero minimum CFM is required, read the differential pressure for the desired CFM from the calibration curve

corresponding to the inlet size of the terminal being calibrated (B-PCOM figure 5). Adjust the LO knob until the desired differential pressure is read on the manometer gauge. Allow several seconds for the controls to react to the system and stabilize.

2. Adjusting maximum air flow:

- a. Apply zero signal to port T on the controller.
- b. Refer again to the calibration curve (B-PCOM figure 5) to determine the differential pressure necessary for the required maximum CFM.
- c. Adjust the HI knob on the controller until the manometer gauge reads the required differential pressure from the curve.

NOTE: If actuator fails to respond, see Guide to Service Procedures B-PCOM.



(Continued on back).

Reset Start Point Instructions for the TITUS II Controller

Setup Procedure (Figure 1)

1. Confirm the setting on the Thermostat adjustment Switch for TITUS II controls.
2. Confirm the setting on the Damper Switch.
3. Disconnect the red HI and green LO lines from the controller.
4. Detach the white thermostat line from Port T on the controller. Attach a squeeze bulb with 0 to 25 PSI gauge to Port T.
5. Remove the yellow motor line from Port B on the controller. Attach a 0 to 25 PSI gauge to Port B.

To Adjust the Start Point

Direct-Acting Thermostats:

1. Apply zero PSI to thermostat Port T.
2. Adjust the LO knob on the face of the controller until the gauge on Port B reads:
 - 2 PSI for normally closed terminals [or]
 - 15 PSI for normally open terminals.
3. Use the Squeeze-Bulb to set the thermostat pressure to 8 PSI or (whatever PSI the desired setpoint should be).

4. Adjust the Reset-Start-Point knob until the gauge on Port B reads: (note 1)
 - 4-5 PSI for normally open terminals [or]
 - 10-11 PSI for normally closed terminals.
5. SEE NOTE 2.


Reverse-Acting Thermostats:

1. Apply 15 PSI to thermostat Port T.
2. Adjust the LO knob on the face of the controller until the gauge on Port B reads:
 - 2 PSI for normally closed terminals [or]
 - 15 PSI for normally open terminals.

3. Use the Squeeze-Bulb to set thermostat to desired start-point PSI.
4. Adjust the Reset-Start-Point knob until the gauge on Port B reads: (note 1)
 - 4-5 PSI for normally open terminals [or]
 - 10-11 PSI for normally closed terminals.
5. SEE NOTE 2.

NOTE 1: Pressures shown are for 5-10 PSI actuators. For other spring ranges adjust readings accordingly.

NOTE 2: Reconnect Red-Green-Yellow-White tubes to their proper control terminals. Recalibrate Min./Max. CFM settings in accordance with procedures shown in the proper Installation Manual.



TITUS®

990 Security Row • Richardson, Texas 75081 • 972-699-1030 • FAX 972-918-8880

All rights reserved. No part of this work may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or by any information storage and retrieval system, without permission in writing from TITUS Industries, Inc.

Qwik-Chek Procedure for TITUS I, II, and IIA Controllers

Preparing for Calibration

1. Disconnect the actuator tube (yellow stripe) on controller Port B.
2. Connect squeeze bulb with 0 to 25 PSI gauge to the actuator.
3. Connect 0 to 25 PSI gauge to controller Port B (figure 4).

A. Direct Acting Cooling or Reverse Acting Heating

1. Apply zero PSI to thermostat Port T.
2. Read the differential pressure for the desired Minimum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
3. Pump the squeeze bulb until the desired differential pressure is read on the manometer gauge.
4. Adjust the LO knob on the face of the controller until the gauge on Port B reads 7.5 PSI \pm 1.0 PSI.
5. Read the differential pressure for the desired Maximum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
6. Pump the squeeze bulb until the desired differential pressure is read on the manometer gauge.
7. Adjust the HI knob on the face of the controller until the gauge on Port B reads 7.5 PSI \pm 1.0 PSI.
8. Remove gauges and reconnect actuator to controller Port B.

NOTE: If the actuator fails to respond, see Guide to Service Procedures, page 4.

B. Reverse Acting Cooling or Direct Acting Heating

For TITUS I Controllers

1. Apply zero PSI to thermostat Port T.
2. Read the differential pressure for the desired Maximum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
3. Pump the squeeze bulb until the desired

differential pressure is read on the manometer gauge.

4. Adjust the HI knob on the face of the controller until the gauge on Port B reads 7.5 PSI \pm 1.0 PSI.
5. Read the differential pressure for the desired Minimum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
6. Pump the squeeze bulb until the desired differential pressure is read on the manometer gauge.
7. Adjust the LO knob on the face of the controller until the gauge on Port B reads 7.5 PSI \pm 1.0 PSI.
8. Remove gauges and reconnect actuator to controller Port B.

NOTE: If the actuator fails to respond, see Guide to Service Procedures page 4.

For TITUS IIA Controllers

1. Apply zero PSI to thermostat Port T.
2. Read the differential pressure for the desired Maximum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
3. Pump the squeeze bulb until the desired differential pressure is read on the manometer gauge.
4. Adjust the LO knob on the face of the controller until the gauge on Port B 7.5 PSI \pm 1.0 PSI.
5. Read the differential pressure for the desired Minimum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
6. Pump the squeeze bulb until the desired differential pressure is read on the manometer gauge.
7. Adjust the HI knob on the face of the controller until the gauge on Port B reads 7.5 PSI \pm 1.0 PSI.
8. Remove gauges and reconnect actuator to controller Port B.

NOTE: If the actuator fails to respond, see Guide to Service Procedures page 4.

For TITUS II Controllers

1. Apply 15 to 25 PSI to thermostat Port T.
2. Read the differential pressure for the desired Minimum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
3. Pump the squeeze bulb until the desired differential pressure is read on the manometer gauge.
4. Adjust the LO knob on the face of the controller until the gauge on Port B reads 7.5 PSI \pm 1.0 PSI.
5. Read the differential pressure for the desired Maximum CFM from the calibration curve corresponding to the inlet size of the terminal being calibrated (figure 5 or 6).
6. Pump the squeeze bulb until the desired differential pressure is read on the manometer gauge.
7. Adjust the HI knob on the face of the controller until the gauge on Port B reads 7.5 PSI \pm 1.0 PSI.
8. Remove gauges and reconnect actuator to controller Port B.

NOTE: If the actuator fails to respond, see Guide to Service Procedures page 4.




FIGURE 4

Replacement Parts

Description	Part Number
1. Actuators	
Krueler MCP-8031	10058501
Johnson D-3062	10058601
2. Actuator Crank Arms	
Krueler	30192002
Johnson	30192006
3. Act. Mtg. Plate-RH/LH	
	70560301
4. Controllers	
TITUS I DA (Beige)	10015001
TITUS I RA (Gray)	10015101
TITUS II	70500001
TITUS IIA	10065001
TITUS III	70743201
5. Room Thermostats	
Std. DA one pipe	10182203
Std. RA one pipe	10182204
Std. DA two pipe	10182201
Std. RA two pipe	10182202
Rosinctor Tee (.005)	41410174
Pneumatic Ctl. Mtg. Brkt.	
TITUS I	70267002
TITUS II, IIA, III	70382901
Controller Box	
Enclosure	
TITUS II, IIA, III	70073401
Cover	
TITUS II, IIA, III	70073501
Enclosure TITUS I	70287201
Cover TITUS I	70267101

Guide To Service Procedures


Symptom	Probable Cause	Correction
Actuator will not stroke. (Generally any setting of the damper compatibility selector on the face of the controller).	<ol style="list-style-type: none"> 1. Leak in the control line between the controller and the actuator. 2. Leak in the actuator. 3. Insufficient main air supply pressure. 4. Faulty controller. 5. Pneumatic thermostat and main air line connections are reversed at the controller. 6. Control lines from the sensor to the controller are reversed. 	<ol style="list-style-type: none"> 1. Repair the leak. 2. Apply 15-25 psi air from the main air supply to the actuator. The actuator should stroke. Pinch the air supply line. If the actuator retracts, it is leaking. Replace the actuator and contact your TITUS distributor. 3. The controller must receive compressed air from the main supply at 15-25 psi. Be sure all connections are as shown in Figure 4. 4. If the controller appears to be faulty, contact your TITUS distributor. 5. See Figure 4. The thermostat must be connected to Port T and the main air to Port M. 6. See Figure 4. Make the connections as shown.
Actuator will not stroke. (Normally open setting of the damper compatibility selector on the face of the controller).	<ol style="list-style-type: none"> 1-6. As above. 7. Rubber caps on HI or both balancing tees are missing. 8. HI control line or the HI passage of the sensor is plugged. 9. Damper compatibility selector on the face of the controller is set wrong. 10. Low differential pressure at the sensor. 	<ol style="list-style-type: none"> 1-6. As above. 7. Replace the caps on the balancing tees. 8. Clean out the passage or control line. 9. Set the damper compatibility selector to match the action of the damper. 10. Increase the air flow rate to the terminal inlet if necessary.
Actuator will not stroke. (Normally closed setting of the damper compatibility selector on the face of the controller).	<ol style="list-style-type: none"> 1-6. As above. 7. Rubber cap on the LO balancing tee is missing. 8. LO control line or the LO passage in the sensor is plugged. 	<ol style="list-style-type: none"> 1-6. As above. 7. Replace the cap. 8. Clean out the passage or control line.
Actuator remains fully stroked at all times. (Normally open setting of the damper compatibility selector on the face of the controller).	<ol style="list-style-type: none"> 1. Faulty controller. 2. Rubber cap on the LO balancing tee is missing. 3. LO control line or the LO passage of the sensor is plugged. 	<ol style="list-style-type: none"> 1. If the controller appears to be faulty, contact your TITUS Products distributor. 2. Replace the cap. 3. Clean out the passage or control line.
Actuator remains fully stroked at all times. (Normally open setting of the damper compatibility selector on the face of the controller).	<ol style="list-style-type: none"> 1. Faulty controller. 2. Control lines from the sensor to the controller are reversed. 3. Rubber caps on HI or both balancing tees are missing. 4. HI control line or the HI passage of the sensor is plugged. 5. Damper compatibility selector on the face of the controller is set wrong. 6. Low differential pressure at the sensor. 	<ol style="list-style-type: none"> 1. If the controller appears to be faulty, contact your TITUS Products distributor. 2. See Figure 8. Make the connections as shown. 3. Replace the caps on the balancing tees. 4. Clean out the passage or control line. 5. Set the damper compatibility selector to match the action of the damper. 6. Increase the air flow rate to the terminal inlet if necessary.
Inaccurate or erratic air flow control.	<ol style="list-style-type: none"> 1. Poor inlet duct connection. 2. Leakage in the duct work. 3. Assembly mounted in a non-level position or upside down. 4. Controller adjustment dials are not set correctly. 5. Low velocity pressure in the inlet duct. 6. Thermostat compatibility selector on the face of the controller is set wrong. 7. Thermostat is out of calibration. 	<ol style="list-style-type: none"> 1. Check inlet duct for blockage or kinks. 2. Repair the leakage. 3. Control must be horizontal ± 10 degrees. 4. See "Adjusting the Minimum and Maximum Air Flow". 5. Increase the air flow rate to the terminal inlet if necessary. 6. Set the thermostat compatibility selector to match the action of the thermostat. 7. Turn the thermostat adjusting dial through its full travel. The air pressure signal delivered by the thermostat to Port T on the back of the controller must vary from 0 to main air supply pressure (15-25 psi). If this pressure range is not correct, recalibrate the thermostat or consult your TITUS Products distributor.

TITUS®

990 Security Row • Richardson, Texas 75081 • 972-699-1030 • FAX 972-918-8880

Copyright © 1999 TITUS Products, Inc. All rights reserved. This manual is the property of TITUS Products, Inc. and is loaned to you for your use only. It is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage or retrieval system, without the prior written permission of TITUS Products, Inc.

MULTI-POINT INLET SENSOR



Inlet Duct Applications:


Inlet Size Code	K-Factor (CFM)
04	269
05	404
06	474
07	625
08	881
09	1094
10	1371
12	1931
14	2785
16	3877
40 (24x16)	7784

FIGURE 5

$$CFM = \sqrt{DP} \times K$$

$$DP = \left(\frac{CFM}{K}\right)^2$$

MULTI-POINT DISCHARGE SENSOR



Dual Duct Discharge/EDV & MDV

Terminal Unit Size	Sensor Size	K-Factor (CFM)
04	04	236
05	06	406
06	07	504
07	08	714
08	09	935
09	12	1281
10	12	1675
12	14	2428
14	16	3647
16	16	4607

FIGURE 6