


COUNTERFLOW WALL FURNACE PARTS LIST

Natural Gas: CF403D-H, CF553D-H, CF407D-H, CF557D-H
 Propane Gas: CF404D-H, CF554D-H, CF408D-H, CF558D-H



ATTN: CONTRACTORS AND QUALIFIED SERVICE TECHNICIANS:

We only sell parts through our wholesalers. For prompt parts service, contact the wholesaler from which you purchased your Cozy heater.

HOW TO PROPERLY ORDER PARTS:

In addition to the part description and numbers, please be prepared to provide:

- Model Number
- Serial Number
- Type of Gas Used

This information can be found on the rating plate that is attached to the heater.

COUNTERFLOW WALL FURNACE PARTS LIST

Natural Gas: CF403D-H, CF553D-H, CF407D-H, CF557D-H
 Propane Gas: CF404D-H, CF554D-H, CF408D-H, CF558D-H

REF. #	PART DESCRIPTION	STANDING PILOT MODELS				IID PILOT MODELS			
		Natural Gas Model Numbers		Propane Gas Model Numbers		Natural Gas Model Numbers		Propane Gas Model Numbers	
		CF403 D-H	CF404 D-H	CF553 D-H	CF554 D-H	CF407 D-H	CF408 D-H	CF557 D-H	CF558 D-H
REF. #	PART DESCRIPTION	PART NO.	PART NO.	PART NO.	PART NO.	PART NO.	PART NO.		
1	Casing Side, Right	30325	30525	30325	30525				
1A	Casing Side, Left	30330	30530	30330	30530				
1B	Center Back Assembly	30364	30544	30364	30544				
1C	Top Assembly	30025	30025	30025	30025				
1D	Upper Back Assembly	30070	30070	30070	30070				
1E	Lower Back Assembly	30219	30219	30219	30219				
1F	Bottom	30246	30246	30246	30246				
2	Liner Assembly	30370	30550	30370	30550				
3	Header Assembly Complete	31399	31399	31399	31399				
4	Heat Exchanger Assembly	30378	30581 30565	30378	30581 30565				
5	Draft Diverter Assembly	30400	30400	30400	30400				
6	Fan Shroud Assembly	30200	30200	30200	30200				
7	Top Louver w/ Insulation	30087	30087	30087	30087				
8	Center Front Panel w/ Insulation	30359	30534	30359	30534				
9	Bottom Louver Assembly w/ Insulation	30100	30100	30100	30100				
10	Upper Front Shield	30250	30250	30250	30250				
11	Switch Box	30252 30450	30252 30450	30252 30450	30252 30450				
12	Switch Box Cover	30253	30253	30253	30253				
13	Lower Front Shield	30256	30256	30256	30256				
14	Motor Mounting Bracket	*30079	*30079	*30079	*30079				
15	Junction Box Cover	30033	30033	30033	30033				
19	Wiring Harness	78251	78252	78252	78257				
24	Fan Motor	78111	78111	78111	78111				
25	Fan Blade	72111	72111	72111	72111				
26	Rubber Grommet (Requires 4)	**78010	**78010	**78010	**78010				
27	Limit Switch 60T11-L180	78065	78065	78065	78065				
28	Fan Switch 60T12-F120	78064 78067	78064 78067	78064 78067	78064 78067				
29	Speed Switch 60T13-F160-30	78066	78066	78066	78066				
30	Auxiliary Limit Switch 60T15-L350	78086	78086	78086	78086				
32	Transformer	78069	78069	78069	78069				
32B	Flue Pipe Adapter	40061	40061	40061	40061				
32C	Plug Bracket	30047	30047	30047	30047				
32D	Casing Mounting Brackets	*30260	*30260	*30260	*30260				
33	Flue Pipe Gasket - 4x8-7/16"	78050	78050	78050	78050				
34	Draft Diverter Gasket - 7x8"	78051	78051	78051	78051				
34B	Casing Top Gasket - 8-1/2x4-1/2"	78155	78155	78155	78155				
35	Element Support Gasket - 9-1/2x14-1/4"	78052	78052	78052	78052				
37	Cozy Handle	84003	84003	84003	84003				
39	Snap-in Outlet	78058	78058	78058	78058				
45	Blocked Flue Switch	78107	78109	78107	78109				
46	Blocked Flue Switch Wire	78230	78230	78230	78230				

NOTE: Parts & schematic drawings on current models are shown at: cozyheaters.com | Specifications subject to change without notice.

* Requires 2 ** Requires 4