3RU21 up to 100 A, CLASS 10

# Description

The 3RU thermal overload relays up to 100 A are designed for current-dependent protection of applications with normal start-up conditions (see "Trip classes") against impermissibly high rises in temperature as a result of overload or phase failure (see "Phase failure protection"). An overload or phase failure causes the motor current to rise above the set rated motor current (see "Setting"). This current rise heats up the bimetal strips within the relay via heating elements which, in turn, operate the auxiliary contacts via a tripping mechanism due to their deflection (see "Auxiliary contacts"). These switch the load off via a contactor. The switch-off time is dependent on the ratio of tripping current to operational current  $I_{\rm e}$  and is stored in the form of a tripping characteristic with long-term stability (see "Tripping characteristics"). The "Tripped" state is signalled by means of a switching position indicator (see "Indication of status").

Resetting takes place manually or automatically (see "Manual and automatic resetting") after a recovery time has elapsed (see "Recovery time").

The 3RU thermal overload relays are electrically and mechanically optimised to the 3RT contactors such that, in addition to individual mounting, they can also be directly mounted onto the contactors to save space (see "Design and mounting"). The main and auxiliary circuits can be connected in various ways (see "Connection"), including the use of Cage Clamp terminals. When the overload relay has been connected, it can be tested for correct functioning us-ing a TEST slide (see "TEST function"). In addition to the TEST function, the 3RU thermal overload relay is equipped with a STOP function (see "STOP function").

For a wide variety of application possibilities for the 3RU thermal overload relay, please refer to the sections "Application", "Ambient conditions", "Overload relays in WYE-delta combinations" and "Operation with frequency converters".

The 3RU thermal overload relays can protect your loads from overload and phase failure. You must implement short-circuit protection (see "Short-circuit protection") by means of a fuse or circuit-breaker.

The 3RU thermal overload relays are environmentally friendly

3/8

(see "Environmental considerations") and comply with all the main international standards and approvals (see "Specifications" and "Increased safety type of protection EEx").

The accessories for the 3RU thermal overload relays have been designed on the principle that all requirements are covered by a small number of variants

#### Application

The 3RU thermal overload relays are designed for the protection of three-phase and singlephase AC and DC motors

If single-phase AC or DC loads are to be protected using 3RU thermal overload relays, all three bimetal strips should be heated. Therefore all main circuits of the relay must be connected in series

#### **Overload relays in WYE-delta** combinations

When overload relays are used in WYE-delta combinations, it is important to note that only  $1/\sqrt{3}$ of the motor current flows through the mains contactor. An overload relay mounted on the main contactor must be set to 0.58 times the motor current.

A second overload relay must be mounted on the star contactor if your load is also to be optimally protected in WYE operation. The WYE current is 1/3 of the rated motor current. The relevant relay must be set to this current.


#### Control circuit

An additional power supply is not required for operation of the 3RU thermal overload relays.

#### Ambient conditions

The 3RU thermal overload relays are temperature compensating according to IEC 60 947-4-1/DIN VDE 0660 Part 102 in the temperature range -20 °C to +60 °C. For temperatures from +60 °C to +80 °C, the upper setting value of the setting range must be reduced by a specific factor as given in the table below.

Reduction factor for the upper set- ting value
1.0
0.94
0.87
0.81
0.73



#### Connection for mounting onto contactors:

Optimally adapted in electrical, mechanical and design terms to the contactors. The overload relay can be connected directly to these contactor using these pins. Stand-alone installation is possible as an alternative (in conjunction with a terminal bracket for stand-alone installation).

# 2 Selector switch for manual/automatic RESET and RESET button: With this switch you can choose between manual and automatic RESET. A device set to manual RESET can be reset locally by pressing the RESET button. A remote RESET is possible using the RESET modules (accessories), which are independent of size.

Switch position indicator and TEST function of the wiring: Indicates a trip and enables the wiring test.

Motor current setting: Setting the device to the rated motor current is easy with the large rotary knob.

#### 5 STOP button:

If the STOP button is pressed, the NC contact is opened. This switches off the contactor downstream. The NC contact is closed again when the button is released.

#### 6 Supply terminals:

Depending on the device version, the terminals for screw, spring-type or ring lug terminal connection are configured for the main and auxiliary circuit.

A sealable transparent cover can be optionally mounted (accessory). It secures the motor current setting against adjustment

3RU21 26-4FB00 thermal overload relays

#### Trip classes

The 3RU thermal overload relay is available for normal startup conditions in CLASS 10. For further details about trip classes, see "Tripping characteristics".

## Tripping characteristics

The tripping characteristics show the relationship between the tripping time and the tripping current as a multiple of the operational current Ie and are specified for symmetrical three-pole and two-pole loading from cold.

The smallest current at which tripping occurs is called the limiting tripping current. In accor-dance with IEC 60 947-4-1/ DIN VDE 0660 Part 102, this must lie within certain specified limits. The limits of the limiting tripping current lie, in the case of the 3RU11 thermal overload relay for symmetrical three-pole loading between 105 % and 120 % of the operational current. Starting from the limiting tripping current, the tripping characteristic moves on to larger tripping currents based on the characteristics of the so-called trip classes (CLASS 10, CLASS 20 etc.). The trip classes describe time-intervals within which the overload relay must trip with 7.2 times the operational current  $I_{o}$ for symmetrical three-pole loading from cold.

#### The tripping times are:


CLASS	Tripping times
10A	2 s to 10 s
10	4 s to 10 s
20	6 s to 20 s
30	9 s to 30 s



# 3RU21 up to 100 A, CLASS 10

## Description

This is the schematic representation of a characteristic. The characteristics of the individual 3RU thermal overload relays can be requested from Technical Assistance at the e-mail address: nst.technical-assistance@siemens.de



The tripping characteristic of a three-pole 3RU thermal overload relay (see characteristic for symmetrical three-pole loading from cold) is valid when all three bimetal strips are loaded with the same current simultaneously. If, however, only two bimetal strips are heated as a result of phase failure, these two strips would have to provide the force necessary for operating the release mechanism and, if no additional measures were implemented, they would require a longer tripping time or a higher current. These increased current levels over long periods usually result in damage to the consumer. To prevent damage, the 3RU thermal overload relay features phase failure sensitivity which, thanks to an appropriate mechanical mechanism, results in accelerated tripping according to the characteristic for two-pole loading from cold.

In contrast to a load in the cold state, a load at operating temperature has a lower heat reserve. This fact affects the 3RU thermal overload relay in that following an extended period of loading at operational current  $I_{\rm e}$ , the tripping time reduces by about a quarter.

#### Phase failure protection

The 3RU thermal overload relays feature phase failure protection (see "Tripping characteristics") for the purpose of minimizing the heating of the load during single-phase operation as a result of phase failure.

## Setting

The 3RU thermal overload relay is adjusted to the rated motor current using a rotary knob. The scale of the rotary knob is calibrated in Amperes.

# Manual and automatic resetting

It is possible to switch between manual resetting and automatic resetting by depressing and rotating the blue button (RESET button). When manual resetting is selected, a reset can be performed directly on the device by pressing the RESET button. Remote resetting can be implemented by using the mechanical and electrical RE-SET modules from the range of accessories (see "Accessories"). When the blue button is set to Automatic RESET, the relay will be reset automatically.

A reset is not possible until the recovery time has elapsed (see "Recovery time").

#### **Recovery time**

After tripping due to an overload, it takes a certain length of time for the bimetal strips of the 3RU thermal overload relays to cool down. The relay can only be reset once it has cooled down. This time (recovery time) is dependent on the tripping characteristic and the level of the tripping current.

After tripping due to overload, the recovery time allows the load to cool down.

## **TEST** function

Correct functioning of the ready 3RU thermal overload relay can be tested with the TEST slide. The slide is operated to simulate tripping of the relay. During this simulation, the NC contact (95-96) is opened and the NO contact (97-98) is closed whereby the overload relay checks that the auxiliary circuit is wired correctly. When the 3RU thermal overload relay is set to Automatic RESET, an automatic reset takes place when the TEST slide is released. The relay must be reset using the RESET button when it is set to Manual RESET.

# **STOP** function

When the STOP button is pressed, the NC contact is opened and the series-connected contactor and therefore the load is switched Off. The load is reconnected via the contactor when the STOP button is released.

#### Status indication

The current status of the 3RU thermal overload relay is indicated by the position of the marking on the "TEST function/switching position indicator" slide. The marking on the slide is on the left at the "O" mark following a trip due to overload or phase failure and at the "I" mark otherwise.

#### Auxiliary contacts

The 3RU thermal overload relay is equipped with an NO contact for the tripped signal and an NC contact for switching off the contactor.

#### Connection

All the 3RU thermal overload relays have screw terminals for the main and auxiliary circuits. Once the box terminals have been removed from the main conductor connections of the overload relays of size S3, it is possible to connect busbars.

Alternatively the devices are available with either spring loaded or with ring lug terminals on both the control and the main terminals. For details of various connection possibilities, see the "Technical data" and "Selection and ordering data"

#### Design and mounting

The 3RU thermal overload relays are suitable for direct mounting on the 3RT contactors. They can also be mounted as single units if the appropriate adapters are used. For details of the mounting possibilities, see the "Selection and ordering data" and the "Technical data".

# Operation with frequency converters

The 3RU thermal overload relays are suitable for operation with frequency converters. Depending on the frequency of the converter, a current higher than the motor current may have to be set due to the occurrence of eddy currents and skin effects.

#### **Environmental considerations**

The devices are manufactured taking environmental considerations into account and comprise environmentally-friendly and recyclable materials.

#### **Specifications**

The 3RU thermal overload relays comply with the requirements of:

- IEC 60 947-1/
- DIN VDE 0660 Part 100 • IEC 60 947-4-1/
- DIN VDE 0660 Part 102
- DIN VDE 0660 Part 200
- IEC 60801-2, -3, -4, -5 and
- UL 508/CSA C 22.2.

The 3RU11 thermal overload relays are also safe from touch according to DIN VDE 0106 Part 100 and climate-proof to IEC 721.

#### Degree of protection "Increased safety" EEx

The 3RU thermal overload relay meets the requirements for overload protection of motors of the "Increased safety" type of protection EEx e IEC 50 019/ DIN VDE 0165, DIN VDE 0170, DIN VDE 171. KEMA test certificate number Ex-97.Y.3235, DMT 98 ATEX G001, EN 50 019: 1977 + A1 ... A5, Increased Safety "e": Appendix A, Guideline for temperature monitoring of squirrel cage motors during operation.

#### **Accessories**

For the 3RU thermal overload relay, there are:

- one adapter for each of the four overload relay sizes S00 to S3 for individual mounting
- S3 for individual mounting • one electrical remote RESET module for all sizes in three different voltage variants
- one mechanical remote RESET module for all sizes
- one cable release for all sizes
- for resetting inaccessible devices
- terminal covers

The accessories can also be used for the 3RB solid state overload relay.



# 3RU21 up to 100 A, CLASS 10

# SIRIUS

## Selection and ordering data

- Features and technical characteristics
  - Auxiliary contacts: 1 NO + 1 NC
- Manual/automatic RESET •
- Switching position indication .
- CLASS 10

•

• Sealable cover: optional in S00, S0 & S2. Integrated in S3 •

3RU2126-4NB0

•

•

**TEST** function

STOP button

Туре

Phase failure sensitivity

- For description, see page 3/8
- For technical data, see pages 3/12-3/15
- For circuit diagrams, see page 3/15
- For dimension drawings, see page 3/16-3/17.

Screw	Direct to Contactor	B0
Screw <sup>1)</sup>	Stand Alone	B1
Spring <sup>2)</sup>	Direct to Contactor	C0
Spring <sup>1) 2)</sup>	Stand Alone	C1
Ring Lug	Direct to Contactor	JO

•• Terminal Types I

Mounting Type

Ltr

<b>†† Terminal Types II</b>							
Туре	Type Mounting Type						
Screw	Direct to Contactor	B0					
Screw 4)	Stand Alone	B1					
Spring 3)	Direct to Contactor	D0					
Spring 3) 4)	Stand Alone	D1					



3RU2146-4JB0



Number combination from the

Terminal types II table



3RU2116-1GB0

3RU2116-1GC0

# Thermal Overload Relays up to 40A Frame Size S00 and S0 \*\*

Setting Range A	Order No.	Setting Range A	Order No.	Weight approx. (screw/ spring) kg
	e S00: For mou		y to 3RT201 co	ontactors
or for stan	d-alone installa	luon		
0.11 - 0.16	3RU2116-0A••	1.4 - 2	3RU2116-1B••	
0.14 - 0.2	3RU2116-0B••	1.8 - 2.5	3RU2116-1C••	
0.18 - 0.25	3RU2116-0C••	2.2 - 3.2	3RU2116-1D••	0.13/0.15
0.22 - 0.32	3RU2116-0D••	2.8 - 4	3RU2116-1E••	
0.28 - 0.4	3RU2116-0E••	3.5 - 5	3RU2116-1F••	
0.35 - 0.5	3RU2116-0F••	4.5 - 6.3	3RU2116-1G••	a . a /a . F
0.45 - 0.63	3RU2116-0G••	5.5 - 8	3RU2116-1H••	0.13/0.15
0.55 - 0.8	3RU2116-0H••	7 - 10	3RU2116-1J••	
0.7 - 1	3RU2116-0J••	9 - 12.5	3RU2116-1K••	
0.9 - 1.25	3RU2116-0K••	11 - 16	3RU2116-4A••	0.13/0.15
1.1 - 1.6	3RU2116-1A••			
	e S0: For moun d-alone installa	•	to 3RT202 cor	tactors

or for stan	d-alone Installa	ation		
1.8 - 2.5	3RU2126-1C••	11 - 16	3RU2126-4A••	
2.2 - 3.2	3RU2126-1D••	14 - 20	3RU2126-4B••	0 10/0 00
2.8 - 4	3RU2126-1E••	17 - 22	3RU2126-4C••	0.16/0.22
3.5 - 5	3RU2126-1F••	20 - 25	3RU2126-4D••	
4.5 - 6.3	3RU2126-1G••	23 - 28	3RU2126-4N••	
5.5 - 8	3RU2126-1H••	27 - 32	3RU2126-4E••	
7 - 10	3RU2126-1J••	30 - 36	3RU2126-4P••	0.16/0.22
9 - 12.5	3RU2126-1K••	34 - 40	3RU2126-4F••	

Thermal Overload Relays up to 100A Frame Size S2 and S3 <sup>††</sup>

3RU2136-4RB1

Setting Range A	Order No.	Setting Range A	Order No.	Weight approx. (screw/ spring) kg
Frame Siz	e S2: For moun	tina directly	to	
	ontactors <sup>4)</sup>			
22 - 32	3RU2136-4E††	47 - 57	3RU2136-4Q††	
28 - 40	3RU2136-4F††	54 - 65	3RU2136-4J††	0.04
36 - 45	3RU2136-4G††	62 - 73	3RU2136-4K††	0.34
40 - 50	3RU2136-4H††	70 - 80	3RU2136-4R††	
	e S3: For mour	ting directly	to	
3RT104 co	ontactors <sup>4)</sup>			
28 - 40	3RU2146-4F††	70 - 90	3RU2146-4L++	
36 - 50	3RU2146-4H††	80 - 100	3RU2146-4M††	

<sup>1)</sup> Not available for size S0 3RU212 with current setting range below 14 A.

<sup>2)</sup> Size S00 and S0: main and auxiliary conductor terminals are spring-type.

- <sup>3)</sup> Size S2 and S3 auxiliary terminals are spring-type only. Main conductor terminals are screw.
- <sup>4)</sup> 3RU Overloads in S2 and S3 frame are available preassembled with a terminal bracket for standalone mounting. S2 and S3 overloads can also be customer assembled to the terminal bracket (see Accessories).

**Ordering information** Replace the (••) with the letter Number combination from the Terminal types I table • Replace the ( **††**) with the letter

# **Overload Relays**

Accessories

3RU up to 100 A



Accessories

Accessories					
	Design		for type	Order No.	Weight approx
			Size		kg
Terminal brackets for s	tand-alone installation 1) For separate mounting of the overload rel panel mount or snapped onto 35 mm standard mounting rail, size S3 also for 75 mm standard mounting	terminals	S00 S0 S2 S3	3RU29 16-3AA01 3RU29 26-3AA01 3RU29 36-3AA01 3RU29 36-3AA01 3RU29 46-3AA01	0.04 0.05 0.18 0.28
		Spring Loaded terminals	S00 S0	3RU29 16-3AC01 3RU29 26-3AC01	0.04 0.06
RU29 36-3AA01					
Mechanical RESET	Resetting plunger, holder, and former o	overload reset adapter	S00 to S3	3RU29 00-1A	0.038
1 million	Pushbuttons with extended stroke		S00 to S3	3SB3000-0EA11	0.020
with	Extension plungers For compensation of the distance bewtee the unlatching button of the relay	n the pushbutton and	S00 to S3	3SX1 335	0.004
pushbutton, and reset 3RU19 00-1A extension	Complete mechanical reset assembly		S00 to S3	3SBES-RESET	
Cable release with hold	er for RESET				
	For drilled hole Ø 6.5 mm in the control panel max. control panel thickness 8 mm	Length 400 mm Length 600 mm	S00 to S3 S00 to S3	3RU29 00-1B 3RU29 00-1C	0.063 0.073
BRU19 00-1					
Module for remote RES		000 to 0	0		
	Operating range 0.85 to $1.1 \times U_s$ Power consumption AC 80 VA, DC 70 W ON period 0.2 s to 4 s AC/DC 24 V to 30 V AC/DC 110 V to 127 V AC/DC 220 V to 250 V	S00 to S	3	3RU19 00-2AB71 3RU19 00-2AF71 3RU19 00-2AM71	0.066 0.066 0.066
3RU19 00-2A.71					
Terminal cover					
	Cover for cable lug and bar connection	S3		3RT19 46-4EA1	0.040
BRT1946-4EA1	Cover for box terminals	\$2 \$3		3RT29 36-4EA2 3RT19 46-4EA2	0.020 0.025
Sealable covers					
	For covering the rotary setting dials. Order in multiples of 10.		S00 to S2	3RV29 08-0P	0.100
3RV29 08-0P					
Tool for opening Spring	J Loaded terminal connections Suitable up to a				
	For all SIRIUS devices with spring-type te	rminals			
3RA2908-1A	<ul> <li>Length: approx. 200 mm;</li> <li>3.0 × 0.5 mm (green)</li> </ul>			3RA2908-1A	0.045

<sup>1)</sup> The accessories are identical to those of the 3RB30/3RB31 solid-state overload relays.

# 3RU21 up to 100 A, CLASS 10



Technical data

Type Size			3RU21 16 S00	3RU21 26 S0	3RU21 36 S2	3RU21 46 S3
Width			45 mm	45 mm	55 mm	70 mm
General data						
Release on			overload or pha	se failure		
Trip class	acc. to IEC 60 947-4-1	CLASS	10		10, 10A	10
Phase failure sensitivity			Yes			
Overload warning			No			
Resetting and recovery Reset possibilities after tripping Recovery time	on automatic RESET on manual RESET on remote RESET	min min min	depending on the depending on the depending on the dependence of t	ne level of tripping a	ET <sup>1)</sup> current and the tripp current and the tripp current and the tripp	ing characteristic
Features Indication of status on the device TEST function RESET button STOP button			Yes, using the s Yes Yes Yes	lide "TEST function/	ON-OFF indicator"	
	ncreased safety" type of protection cording to directive 94/9/EC (ATEX)		DMT 98 ATEX G	6 001 🐼 II (2) GD	On request	
Ambient temperatures Storage/transport Operation Temperature compensation Permissible rated current at	Internal cabinet temperature of 60 °C		-55 to +80 -40 to +70 up to +60 100 (over +60°C the current mus 87			-55 to +80 -40 to +70 up to +60 100 (over +60' current reduct is not required 87
<b>Repeat terminals</b> Repeat coil terminal Auxiliary switch repeat terminal			Yes Yes	Not required Not required		
Degree of protection	acc. to IEC 60529		IP 20	Notroquirou		IP 20 <sup>2)</sup>
Touch protection	acc. to IEC 61140		Finger-safe for vertical contact from the front Finger-safe only with optional terminal covers			
Shock resistance (sine)	acc. to IEC 60068-2-27	<i>g</i> /ms	15/11 (auxiliary	contacts 95/96 and	97/98: 8g/11ms)	8/10
EMC • Interference immunity			Not relevant			
Emitted interference	(humiditu)	%	Not relevant 90			100
Resistance to extreme climates Dimensions	(numeny)	/0		I drawinga		100
			see dimensiona			
Site altitude Installation angle		m	The permissible vidual mounting area, adjustmer Individual mounting $0^{\circ}$ $135^{\circ}$ $I_{e} \times 1, 1$	are shown in the d it compensation of ting $I_e \times 1,1$ $90^{\circ}$	0° 45° I <sub>e</sub> x 1,1 90° NSB01364	ontactors and inc
Type of installation/mounting 1) Remote RESET in combination 2) Terminal compartment: IP 00 de			with terminal su	contactor/stand-alo pport (For screw ar TH 35 standard mor	nd snap-on	Direct mountin stand-alone installation wit terminal suppor (For screw and snap-on mounti onto TH34 stand mounting rails; size S3 also fo TH 75 standar mounting rail."

# 3RU21 up to 100 A, CLASS 10



## Technical data

Туре			3RU21 16	3RU21 26	3RU21 36	3RU21 46
Size			S00	S0	S2	S3
Width			45 mm	45 mm	55 mm	70 mm
Main circuit						
Rated insulation voltage U <sub>i</sub> (	pollution degree 3)	V	690			1000
Rated impulse withstand vol	tage U <sub>imp</sub>	kV	6			8
Rated operational voltage U	9	V	690			1000
Type of current	DC AC		Yes	nere un te 400 Lin		
Oursent estima	AC	٨	0.11-0.16	nge up to 400 Hz	11-16	18 - 25
Current setting		A	to 11 – 16	1.8 – 2.5 to 34 – 40	up to 70-80	to 80 – 100
Power loss per device (max.	)	W	4.16.3	6.27.5	814	10 to 16.5
Short-circuit protection	With fuse without contactor		See selection and	d ordering data		
	With fuse and contactor			Ŭ,	otection with fuses	/
			circuit-breaker fo			, 
•	en main and auxiliary current paths	V				
Acc. to IEC 60947-1,			440	690: Setting	600	600
Screw terminals or ring term	inal lug connections		440	690: Setting ranges ≤ 25 A	690	690
<ul> <li>Spring - type terminals</li> </ul>			440	440: Setting ranges > 25 A	690	
Connection of the main						
Connection of the main of the			Corour terminal			Sorous
Type of connection			Screw terminals			Screw connection with box
						minal <sup>2)</sup> / bar
-						connection
Screw terminals						
<ul> <li>Terminal screw</li> </ul>			M3, Pozidriv	M4, Pozidriv size 2	M6, Pozidriv	Hexagon soc screw 4 mm
· Operating de l'			size 2		size 2	
Operating devices		mm	Ø5 6	Ø5 6	Ø5 6	Ø5 6
<ul> <li>Tightening torque</li> </ul>		Nm	0.8 to 1.2	2 to 2.5	3 to 4.5	4 to 6
Conductor cross-section	Solid or stranded	mm <sup>2</sup>	$2 \times (0.5 \text{ to } 1.5),$	$2 \times (1 \text{ to } 2.5),$	2x(2.5 to 35)	2 × (2.5 to 16
(min./max.), 1 or 2 wires			2 × (0.75 to 2.5), max. 2 x 4	$2 \times (2.5 \text{ to } 6),$ max. $2 \times$	1x(2.5 to 50)	
			111dA. 2 A 4	(2.5 to 10)		
	Finely stranded with end sleeve	mm <sup>2</sup>	2 × (0.5 to 1.5),	$2 \times (1 \text{ to } 2.5),$	2 x (1 to 25)	2 × (2.5 to 35
			$2 \times (0.75 \text{ to } 2.5)$	2 × (2.5 to 6)	1 x (1 to 35)	1 × (2.5 to 50
				max. 1 x 10		
	AWG conductor con., solid or stranded	AWG	2 x (20 16)	2 x (16 12)	2 x (18 to 2)	$2 \times (10 \text{ to } 1/0)$
			2 x (18 14) 2 x 12	2 x (14 8)	1 × (18 to 1)	1 × (10 to 2/0
	Ribbon cable (No. $\times$ width $\times$ thickness)	mm	-	-	-	$2 \times (6 \times 9 \times 0)$
Bar connection						
<ul> <li>Terminal screw</li> </ul>			-			M 6 × 20
<ul> <li>Tightening torque</li> </ul>		Nm	-			4 to 6
Conductor cross-section	Finely stranded with cable lug	mm <sup>2</sup>	_			2 × 70
(min./max.)	Stranded with cable lug	mm <sup>2</sup>	_			2 × 70
	AWG conductor connections, solid or	AWG	_			2/0
	stranded with cable lug	,				2,0
	With connecting bars (max. width)	mm	-			12
Auxiliary circuit						
Main contacts: Number of NO	D contacts		1			
Number of NO			1			
Assignment of auxiliary con	tacts		1 NO for the sign	al "tripped";		
			1 NC for disconn	ecting the contact	or	
Rated insulation voltage U <sub>i</sub> (		V	690			
Rated impulse withstand vol	tage U <sub>imp</sub>	kV	6			
Switching capacity of auxilia	iry contacts					
NC for AC	Rated operational current $I_{e}$ at $U_{e}$ :					
AC-14/AC-15	• 24 V	A	4			
	• 120 V • 125 V	A A	4			
	• 125 V • 230 V	A	4 3			
	• 400 V	А	2			
	• 600 V	A	0.75			
	• 690 V	A	0.75			

1) For conductor cross-sections for Cage Clamp terminals, see "Connection of the auxiliary circuit."

 The box terminal can be removed. After the box terminal has been removed, bar connection and lug connection is possible.

# 3RU21 up to 100 A, CLASS 10



# Technical data

Type Size			3RU21 16 S00	3RU21 26 S0	3RU21 36 S2	3RU11 46 S3
Width			45 mm	45 mm	55 mm	70 mm
NO for AC AC-14/AC-15	Rated operational current <i>I</i> <sub>e</sub> at <i>U</i> <sub>e</sub> : • 24 V • 120 V • 125 V • 230 V • 400 V • 600 V	A A A A A A	3 3 2 1 0.75 0.75			3 3 2 1 0.6 0.5
NC, NO for DC DC-13	Rated operational current <i>I</i> <sub>e</sub> at <i>U</i> <sub>e</sub> : • 24 V • 60 V • 110 V • 125 V • 220 V	A A A A	1 On request 0.22 0.22 0.11			1 On request 0.22 0.22 0.11
Conventional thermal current $I_{\rm th}$		А	6			6
Contact reliability	(suitable for PLC; 17 V, 5 mA)		Yes			Yes
Short-circuit protection With fuse	Utilization cat. gL/gG fast	A A	6 10			
With miniature circuit-breaker (	,	А	6 <sup>1</sup> )			
Reliable operational voltage for between auxiliary current paths	protective separation acc. to IEC 60947-1	V	440			
Connection of the auxiliary	circuit					
Type of connection			Screw terminal or	Cage Clamp termi	nal	
Connection characteristics			Screw terminals			Cage Clamp terminals
<ul> <li>Terminal screw</li> </ul>			Pozidrive Size 2			-
<ul> <li>Tightening torque</li> </ul>		Nm	0.8 to 1.2			2 × (0.25 to 2.5)
<ul> <li>Conductor cross-sections (min./max.), 1 or 2 wires</li> </ul>	Solid or stranded	mm <sup>2</sup>	$2 \times (0.5 \text{ to } 1.5),$ $2 \times (0.75 \text{ to } 2.5)$			
	Finely stranded without end sleeve	mm <sup>2</sup>	-			2 × (0.25 to 2.5)
	Finely stranded with end sleeve	mm <sup>2</sup>	2 × (0.5 to 1.5), 2 × (0.75 to 2.5)			2 × (0.25 to 1.5)
	AWG conductor connections, solid or stranded	AWG	2 x (20 to 16) 2 x (18 to 14)			2 × (20 to 14)


1) Up to  $I_{\rm k}$   $\leq$  0.5 kA;  $\leq$  260 V.


# 3RU21 up to 100 A, CLASS 10

# Circuit diagrams


1-pole

# Protection of DC motors






## 3RU21 16 overload relay



# 3RU21 26 to 3RU21 46 overload relays



# 3RU21 up to 100 A, CLASS 10




# Dimension drawings

## **Screw connection**


Lateral clearance to grounded components: at least 6 mm.






3RU21 16-..B1

Size S00 with adapter for installation as a single unit with accessories




#### 3RU21 26-..B1 Size S0 with adapter for installation as a single unit

94.7 Ο  $\cap$ C 44.9 45 97.1 0 6  $\Omega O$ 85 4.5



#### 3RU21 36-..B. Size S2

with adapter for installation as a single unit





1) For mounting on 35 mm standard mounting rail (15 mm deep) acc. to EN 50 022

or 75 mm standard mounting rail acc. to EN 50023

## 3RU21 46-..B.

Size S3 with adapter for installation as a single unit






Dimension drawings "Contactor with built-on overload relay" see contactors and contactor combinations.


# 3RU21 up to 100 A, CLASS 10

# Dimension drawings


Spring Loaded terminals Lateral clearance to grounded components: at least 6 mm.








3RU11 46-..D. Size S3






1) For mounting on 35 mm standard mounting rail (15 mm deep) acc. to EN 50 022 or 75 mm standard mounting rail acc. to EN 50 023

Dimension drawings "Contactor with built-on overload relay" see contactors and contactor combinations.


## 3RU21 16 -..C1

Size S00 with with adapter for installation as a single unit

51.45







ω

OVERLOAD RELAYS



3RU2136-..D.

Ο 8 H

E

Size S2

91.2

6.5



